

# WS130 Quick Start Guide



<b>Press</b>	Tare	
<b>Press Twice</b>	APO On/Off	
<b>Hold 2 Seconds</b>	Power On/Off	
<b>Hold 3 Seconds</b>		Calibration Mode
<b>Hold Both 5 Seconds</b>	Factory Reset	

1. Quick **PRESS** a button for the “Press” function.
2. **PRESS** any button **TWICE** within 2 sec. for the “Press Twice” function.
3. **HOLD** any button for 2 sec. for the “Hold 2 Sec.” function.
4. **HOLD** any button for 3 sec. for the “Hold 3 Sec.” function.
5. **HOLD BOTH** buttons for 5 sec. for the “Hold Both 5 Sec.” function.

## Using the WS130

1. Remove the WS130 from its protective case and place on a level and firm surface.
2. Power the WS130 on.
3. Connect to the scale via Bluetooth® in the Appion Central™ app.
4. Tare the WS130 if necessary.
5. Begin weighing your materials.
6. View the readings on a smartphone, tablet, or other device via the Appion Central™ app.



**CAUTION:** Refrigerant recovery cylinders can only be filled to 80% of the maximum capacity per DOT Regulations. Refer to page# 6 in the owners manual for additional information.

**WARNING** TO REDUCE THE RISK OF INJURY OR PRODUCT DAMAGE, READ OPERATION MANUAL PRIOR TO OPERATING PRODUCT.

**Connect the *WS130***  
**with the *Appion Central™* App**



***View Full Product Manuals***



**WARNING** TO REDUCE THE RISK OF INJURY OR PRODUCT  
DAMAGE, READ OPERATION MANUAL PRIOR TO OPERATING PRODUCT.